Note: Always reference and use your current aircraft POH procedures

## **CAPS Deployment Procedure**

- 1. Activation Handle Cover.....REMOVE
- 2. Activation Handle (Both Hands)......PULL STRAIGHT DOWN

Approximately 45 lbs of force is required to active CAPS. Pull the handle with both hands in a chin-up style pull until the handle is fully extended.

## After Deployment:

- 7. Ignition Switch.....OFF
  8. ELT.....ON
  9. Seat Belts and Harnesses .....TIGHTEN
- 10. Loose Items ......SECURE
- 11. Assume emergency landing body position.

Reference the passenger briefing card for the correct emergency landing body position.

12. After the airplane comes to a complete stop, evacuate quickly and move upwind.

In high winds the parachute may inflate and drag the aircraft after touchdown. Remain upwind of the aircraft.

